

***RRP Universal Steering System
(22.2 Handlebars)***

***Part# STR-SYST-UNIV
Color: Black***



Installation Instructions:

RRP Steering System fits on RRP poles and is compatible with OEM Yamaha, UMI, and AC Racing.

1. Install the steering system mounting base using the four M6 x 25mm flat head socket screws, washers and nylock nuts.
2. Grease and Slide the washers and bearing over the recessed piece of the mounting base.
Note: Use a low viscosity synthetic marine grease.
3. Apply a thin film of grease to the large o'ring and install in the steering system base.
4. Install your steering plate.
5. Pack the large thrust bearing with grease and install on the top of the steering plate making sure the washer's grooves are facing the bearing.
6. Apply a thin film of grease to the small o-ring and install into the bearing cup.
7. Grease the inside of the bearing cup and the small o'ring.
8. Screw the bolt threw the bearing cup, the bearing and the mounting base.
Tighten the bolt to your desired feel, and then lock the underside of the bolt with the lock nut
(Do not over tighten)
9. Grease the steering system through the zero on the RRP turn plate every 10 hours of operation.(During the greasing when you see the grease coming out from under the o'ring this indicate that the system is full of grease)

Questions or Comments?

For further assistance, please contact us at www.rickroy.com

DISCLAIMER:

RRP shall take no liability for incidental, consequential or special damages or injury to persons or property from any cause arising from the sale, installation or use of this product.