

RRP Universal Steering System (22.2 Handlebars)

Part# STR-SYST-UNIV
Color: Black or Silver



INSTALLATION INSTRUCTIONS:

RRP Steering System fits on RRP poles and is compatible with OEM Yamaha, UMI, and AC Racing.

1. Install the steering system mounting base using the four M6 x 25mm flat head, washers and nylux nuts.
2. Grease and slide first the washer then the bearing and again the washer over the recessed piece of the mounting base. **Note:** Use a low viscosity synthetic marine grease.
3. Grease the large o-ring and install in the steering system base groove.
4. Install your steering plate over the steering post. Make sure the steering recess on the turn plate is facing up.
5. Again grease and slide the washer then the bearing and again a washer over the top of the steering plate
6. Grease the small o-ring and install in the groove on top of the steering post
7. Grease to the medium o-ring and install into the black bearing cap
8. Install the bearing cap on top of the steering post
9. Screw the bolt threw the bearing cap, the bearing the plate and the mounting base.
Tighten the bolt to your desired feel, and then lock the underside of the bolt with the M10 nylux lock nut
10. Install the zerk fitting on the side of the steering plate and grease the steering system every 10 hours of operation. When adding grease you must turn the steering system slowly to apply grease evenly in the system.
11. During the greasing when you see the grease coming out from under the seal this indicate that the system is full of grease
12. **Warning:** Don't apply too much pressure when installing grease to avoid blowing out the o-ring.

Questions or Comments?

For further assistance, please contact us at www.rickroy.com

DISCLAIMER:

RRP shall take no liability for incidental, consequential or special damages or injury to persons or property from any cause arising from the sale, installation or use of this product.

